


INSTALLATION DIAGRAM FOR TITAN SCR-2 N-100



Warning

NEVER weld the unit to the cooper pipe

IMPORTANT NOTES

1. Do not Open the unit under any circumstances .This would void the warranty
2. Always use the wire that comes with the unit from that, connect the junction box or the disconnect sw and then the sugested wire size to the main panel.
3. When you are welding , the cooper pipes, do it without the unit on place, the heat could damage the electronic device inside